

Master Module

Automation Module

Fader Module

Process Module

Knob Module

Display Module

Display Module: Views

Display Module: Funct

Gain Reduction Meters

Waveform Zooming

Banking Techniques

Banking & Nudging

Managing Views

Process Module: Views

Indicators

Color Coding

Matrix: Gestures

Matrix: Selecting Tracks

Selecting Track Ranges

Attentioning Tracks

Bank to Attentioned

Matrix: Functions

Record Arming Tracks

Matrix: Filtering

Attention Track Knobs

Navigation

Transport Functions

Universe Views

Master Module: Scroller

Master Module: Ops

Master Module: Dyn

Master Module: EQ

Master Module: Pan

Master Module: Hybrid

Global Views

Inserts

Inserts: Expanding

Inserts: Favorites

Sends

Channel: Dyn

Channel: EQ

Channel: Sends

Channel: Send Pan

Channel: Pan

Channel: Inserts

Channel: VCA Masters

Channel: Inputs

Channel: Out Busses

Channel: Output Mult

Channel: Groups

Channel: Instruments

Channel: Heat

Channel: Editing

VCA Masters: Spill

Clear Mode

Parameter Nulling

Management

Copyright 2014 Avid Technology, Inc.



S6 Operation

Assignable Knob

Assignable Knob: All

Automation: Modes

Automation: Indicators

Automation: Selected

Automation: Context

Automation: Matching

Automation: Preview

Softkeys: Editor

Softkeys: Creating 1/4

Softkeys: Creating 2/4

Softkeys: Creating 3/4

Softkeys: Creating 4/4

Expand Mode

Expand: VCA Masters

Expand: Groups

Expand: Inserts

Layouts: Creating

Layouts: Recalling

Layouts: Editing

Console Setup 1/2

Console Setup 2/2

Workstations

Control Room 1/3

Control Room 2/3

Control Room 3/3

Console Prefs

Local Options

KVM Switching

WSControl


Diagnostic Mode

Touchscreen Calibrate

Updating S6 Software




Master Module








Automation Module






Fader Module





Process Module








Knob Module









Display Module









Waveforms and Dual Function + Route




Large Waveforms | Same | Big Drums | Company | Company







Copyright 2014 Avid Technology, Inc.

Display Module: Views











Display Module: Functions



Dynamics Curve



EQ Curve



Panning Plot

Dual Function Views



Routing: I/O & Automation




Inserts: Chain a - h (8)



Input & Preamp (8)



Pan: Plot & Params





Inserts: Parameters: EQ (8)



Sends: a - h (8)



EQ: (4)



Edit Mode: (4)



Bus: Multi-Assign (4)

S6
[Return to Index]



Gain Reduction Metering

Gain Reduction Meters are shown on the Display Modules, Fader Module, and Master Module Home Page. Pro Tools Metering Preferences determine the Scale, Ballistics and Gain Reduction Settings.

No Input

mx chain

Read

No Input


brass 3

Compressor/Limiter
Expander/Gate
Priority Compressor/Limiter
Priority Expander/Gate

All – Summed

Green Downward Reduction Indication on Display Modules

Dynamic Graphs with
Bouncing Level Ball on
Display and Master Module



Prd Chn AUTO a: Prd DX S 20 50 60 -4.2 -0.8 dyn 🔛 DX 2

EQ3 7-Band

ProCompr

PL

Meters Types and Settings follow Pro Tools

> Green LED Gain Reduction Indication on Channel Fader








Waveform Zooming






Variable Zoom: 1 to 60 sec


The time window represented on the Display Modules can be adjusted either from the **Preferences** or by using the **Display** switches on the Master Module.

Display









3 Seconds



Zoom In: 1 Second




Banking Techniques



Bank & Nudge from
Dedicated Switches on the
Master Module



Set the Local Track View Options to Auto-Bank on Attentioned or Selected



Press Select or Attention with Auto-Bank
Preference Enabled





Banking & Nudging






Nudge Left/Right by 1 Track



Bank Left/Right by 8 Strips or the Entire Surface








Bank to First or Last Tracks in Session




Press the Tracks button to access a Matrix View of 72 Tracks per page






Managing Views



Press the **Home** button to access all of the control functions for the Attentioned Track plus the Scrolling Meter Bridge







Process Module: Views

Clear Mode: Clear

Expand Mode: Exp

Global Bypass: In

Editing Mode: Edit

Group Assignment: Grp

Output Busses & Paths: Bus



Config

Input: Inputs & Remote Mic Preamp (Hold for Instruments)

Inserts: Plug-Ins View (Hold for HEAT)

Dyn: Dynamics View

EQ: EQ View

User: Instrument Track View


Sends: Sends View

Pan: Panning View







Indicators





Selected Tracks are indicated with Orange.



A selected track which is also Attentioned is indicated with Orange top and Blue bottom.









Attentioned Tracks are indicated in Blue.





Record (Red), Input (Green), Solo (Yellow) & Mute (Orange).






Color Coding



Waveform, Track & Clip Colors



Track based Color Coding



Track Color Indicators



Color Coded Session Universe & Track Scroller






Matrix: Gestures




Touch Individual Tracks One by One (Channel Select Mode = Sum)


Set Channel Selection behavior from the Local Options



Touch and Hold, then Swipe to add multiples in the same row (Channel Select Mode = Intercancel)



Touch and Hold one track (with one hand) while touching additional Tracks (with second hand) (Channel Select Mode = Intercancel)








Matrix: Selecting Tracks

Choose Select Mode from the Tracks
Matrix and Touch a Track to Select it



To Select Multiple Tracks, Touch and Hold one track while Touching or swiping additional tracks




To Clear Multiple Track Selections hold Option and Touch Tracks





Selecting Track Ranges





Select a Contiguous Range of Tracks




Select

L



Select a Discontiguous Range of Tracks



+



Select All Tracks in Session






Toggle Attention Mode in the Track Matrix and Touch a Track



Press the Channel's Attention
Button



Use the Meter Scroller to **Touch** a Track



Use the Track Scroller to **Touch** a Track




□ Attention Tracks from Meter Scroller
 ☑ Display Selection/Attentioned Track Border on Meter Scroller
 □ Track Scroller Follows Attentioned Track
 ☑ Link Meter Scroller to Track Scroller





Bank to Attentioned





Touching a Track in Tracks view from the Master Module Banks to those channels and populates the Attention Fader on the Automation Module.







Track Color Indicators











Matrix: Functions



Implicitly muted tracks are indicated visually by being darkened in the Tracks Matrix when tracks are soloed.



Choose the operation from the lower right corner of the Tracks page for Record, Input, Solo or Mute. Simply Touch one or multiple tracks to perform the function.



Each individual Track in the Matrix has indicators to show if a track has been Soloed, Muted, Record Enabled or set to Input Monitor.







Toggle into Record mode from Tracks View on the Master Module and simply Touch the Track(s) to arm.

Record Arming Tracks




From the Channelstrip, Press the Rec Button.






Function Scroller and Meter Bridge show a Rec Armed state.




Tracks in Record are highlighted in Red.







Matrix: Filtering




Swipe Left or Right to Filter by Track Type from the Tracks Matrix or simply Touch a Category.



Enable Display Breaks on Track Color to visually separate rows









Attention Track Knobs

ADR_B02 977.2 us cAttack Prod_A03 Prod_A05 ADR_B01 ADR_B02 ADR_B03 From the Master Module, **Touch** a parameter which will be identified by brackets. Now **Touch** an Attention Track Knob to dock the bracketed parameters.



Any set of parameters from a single or multiple functions can be docked onto either set of 4 Attention Track Knobs.



Navigation

Wheel Functions Move Selection (playhead)



Zoom Horizontal

Zoom Vertical

Jump to Previous / __ Next Boundary

Jog / Shuttle \





Transport Functions









Enable Half-Speed Playback





+



Cycle Through Playback Modes





+



Cycle Through Record Modes





Use the Soft Keys Transport
Extras for additional functions
from the Automation Module






□ Attention Tracks from Meter Scroller
 ☑ Display Selection/Attentioned Track Border on Meter Scroller
 □ Track Scroller Follows Attentioned Track
 ☑ Link Meter Scroller to Track Scroller

Universe Views

Simply Touch in the Meter Universe to jump to that channel range.







Simply Touch anywhere in the Universe Bar to jump to that Track range.







Master Module: Function Scroller



Touch or Swipe down to access.



S 6
[Return to Index]




Master Module: Operation


All Functions



Selected Functions




To simplify the list of parameters displayed in the Home view, choose Selected Function for the Knob View







Master Module: DYN



Swipe down from **Dynamics** to display the Gain Transfer Curve and populate the Attention Knobs with the primary dynamics controls

Dynamics plots are currently supported for Avid Channelstrip and Pro Compressor Plug-Ins.





Expander Ratio
Compare



Config

 \odot




EQ Type

Shelf/Para

HM Band

Enable

Master Module: EQ



Swipe down from **EQ** to display the frequency plot and populate the Attention Knobs with the primary EQ controls (4 bands)

EQ plots are currently supported for Avid Channelstrip and EQIII Plug-Ins.






Freq/Q

Toggle



Master Module: Pan



Swipe down from Pan to display the Surround Panner and populate the Attention Knobs with the primary Pan controls.

When Pan is engaged, the center area of the Master Module functions as a Stereo Multi-Touch Surround Panner.

 \odot

∠ Config



Master Module: Hybrid



By engaging the **Lock** functions, different sets of parameters can be targeted to each set of 4 Attention Knobs in addition to populating the center section.

Touch any of the **Sends** (Orange) on screen then **Tap** one of the Left Encoders to assign it. Touch the **Lock** icon for this column.

Touch any EQ (Magenta) parameters on screen then Tap one of the Right Encoders to assign it. Touch Lock.

Swipe Down Pan to access the Multi-Touch Panner interface and maintain the Sends & EQ controls.





Global Views



To change the view of the Knob Modules on all console channels, press All then press the View Mode button from the Process Module. All Mode applies to parameter pages, back keys and view functions.







In All Mode Process Views are applied to All tracks








Touch Inserts from the Function Scroller to populate the Attention Track Knobs

Inserts



Parameters



Inserts



Press Ins on the Process

Module to populate the

Knob Module with Inserts.

Press an **Encoder** while in Inserts view to dive into Plug-In Parameters view.

Press Back (left arrow) switch to return to the previous view.



Use In to bypass the attentioned plug-in.







Inserts: Expanding

Stretch anywhere in the Function Scroller to expand Inserts. Pinch to collapse.



OR







Touch Inserts from the Function Scroller.

Press the Encoder on the Master Module representing the Insert you want to display parameters for.



Press Back on the Master Module to return to Inserts chain view.





Inserts: Favorites








Press the **EQ** or **Dyn** button on the Process Module to add a Favorite plug-in to a channel without previous processing.





Touch Sends from the Function Scroller to populate the Attention Track Knobs with the first 8 sends.







Press Sends on the Process
Module to populate the
Knob Module with Sends.

Simply touch the desired sends from the Attention Track Editor and touch either set of 4 Attention Track Knobs to dock the parameters.



 \bigcirc


 \odot

∠ Config



Channelstrip: DYN






Page Right (more parameters)





Channelstrip: EQ




Page Right (more bands available)





Channelstrip: Sends








FX ST 10 * a * b * fxvrbst2 * fxvrbst1 Sends Pan HEAT HEAT

Channelstrip: Send Panning



Sel Sel -31.7

Stereo Send

(hall)



While in Sends View press an encoder to access the Pan parameters for the chosen Send.

Press the Back button to return to the primary Sends view

Back button


(return up menu)

Copyright 2014 Avid Technology, Inc.






Channelstrip: Pan






Channelstrip: Inserts





Channelstrip: VCA Masters




Page Right (more tracks available)






Channelstrip: Inputs






Channelstrip: Output Busses



In indicates an assignment **SFX.5.0** no output 3 SFX.LCR **FOLEY** SFX.ST Sel **SFX** SFX.L Sel In 2

Use the Back button to return back up a menu





Channelstrip: Output Mult

Press **Bus** on the Process Module to populate the Knob Module with Output Bus Parameters




Push an encoder to make a selection for Output or Bus






+ Indicates a multi-assigned output path routed to both SURROUND and STEREO








Channelstrip: Groups



SS [Return to Index]




Channelstrip: Instruments







Channelstrip: HEAT



S 6
[Return to Index]



Channelstrip: Editing


Move Clip


Trim Head

Fade Out


Fade In

Press Edit to enable simple clip editing from the S6 surface including trim, fades, clip-gain and slipping. A clip can be operated on once it reaches the playhead. Use either the Encoder or the Sel / In buttons to adjust the parameters.





Copyright 2014 Avid Technology, Inc.





Master

VCA Masters: Spill

VCA **vDrums** Mute Slave I. **10** ... • 20

Slave Group Member . 1.1 1.1 1.1 • 20 ** **

• 30

To Spill any VCA Master, Press and hold Menu then Spill L or Spill R to specify the direction to Spill the slaves.

For VCA Masters, the Menu button is indicated with **Green** while Slaves are displayed in Yellow. Dedicated LEDs indicate whether a channel is a Master or Slave as well a member of a Group.








• ∞


Bus

Clear Mode





Parameter Nulling



[Return to Index]



Management











Clear Over Indication on Meters



Clear Soloed Channels





Each Fader Module includes dedicated **Ok** / **Cancel** buttons to Accept or Dismiss Dialogs indicated in **Green**. If the dialog is not on the current Workstation it is indicated in **Orange**.









Assignable Knob








Press Back + any Process Mode to populate the Assignable Knob.

Use the Left / Right Arrows to toggle through the available parameter pages.





(Exp) Exp [Exp] [In] [In] [In [In] o In [In [In] [In] [In [In _ (Edit Edit Edit Edit Grp (Grp [OGrp] Grp Bus





Assignable Knob: All

To change the view of all the Assignable Knobs simultaneously, toggle the All button on, hold the Back button and press a view mode button from the Process Module.













Automation: Changing Modes





Cycle through Automation Modes on Channelstrip



Enable / Disable Automation Trim Mode








Press and Hold a SoftKey
Automation Mode button while
pressing Select on the desired
Channel(s).






Automation: Indicators



Automation Writeable Parameters are displayed in Red.



for Parameter





Automation: All & Selected








Toggle Automation Mode of All Tracks



+







Toggle Automation Mode of Selected Tracks



Press Do To All then

Touch to put All Tracks
into Touch Mode.



Press Do To Sel then
Read to put Selected
Tracks into Read Mode.






Automation: Context









Display Volume Automation for Touched Faders









Display Pan Automation for Touched Encoders











Display Waveform View for Selected Tracks


Add the OPTION key to view the chosen automation playlists on all tracks. Pro Tools will automatically scroll the edit window to display the touched track.






Automation: Matching





To match out of automation on a single channel, simply press the F button.



To match out of all automation globally press Auto Match from the Soft Keys on the Automation Module.





Automation: Preview

Enable automation Preview mode by pressing the Preview Soft Key from the Automation Module.







Ensure that the desired channels are currently set to an automation write mode such as Latch, Touch or Touch/Latch.






Make adjustments to the encoders and faders on the enabled channels. Use **Suspend Preview** to A/B settings, then press **Punch Preview** to punch in the settings. Use **Write to All** to commit and apply the punched automation values to a selected range.





Softkeys: Editor





The Soft Key Editor can be accessed by touching Softkeys from the Settings Menu.

Tap a TFT screen to edit the Soft Key Bank's header label or to use the Bank editing buttons
Use Add to create a blank Bank at the end
Use Clear to erase the commands and layout of the current Bank

Tap a Soft Key Button to edit the Soft Key commands or layout


Select Factory to revert the entire appset back to the factory default settings

Instructional Help Text is provided at the bottom of the page.







Softkeys: Creating [1/4]



Choose the Master or Automation Module to edit with the Soft Keys Editor.



Tap the Soft Key section to edit such as Transport Extras 1 shown above.




Tap Add to create a new, empty bank.






Softkeys: Creating [2/4]

[Return to Index]



Double Tap the Name field to name the Bank using the on-screen keyboard.








Softkeys: Creating [3/4]



Tap a Soft Key within a Bank to Edit.



Tap Add from the editor section.




Tap **EUCON** to access a library of EUCON functions supported by your DAW.










Tap Text/Icon Display Mode to specify the presentation of the icons and text.

Tap the Icon Display (blank by default) to select and assign an icon from the library to the chosen function.



Softkeys: Creating [4/4]



Modifier Locks Shift Mode:

State: Text/Icon Display Mode:

Active Text Below Icon


Hide Big Counter












Expand Mode





Expand spills the parameters from the currently selected function (EQ) to the encoders within that knob module.






Expand: VCA Masters

Press Exp while in Bus View on VCA Channels to Expand and populate the local Knob Module with the group Slaves.














Expand: Groups

Press Exp while in Group View to Expand and populate the local Knob Module with all available Groups.













Expand: Inserts

Press Exp while in Inserts View to Expand and populate the local Knob Module with all Parameters for the current Insert.













Press All + Exp to enable Expand Mode for All Channels. Pressing a view mode button on any channel will populate the local Knob Module with the parameters from that channel.







Press the Layout
Mode button to
enter Layouts




2 Tap to select the track(s) to add to the current Layout. Selected tracks are outlined in Green.

Layouts: Creating





4 Press Store then Tap the layout number to confirm and store the location.





3 Tap the destination block (physical fader location) at the bottom to set the location of the selected tracks. Tracks are Left-Justified from the chosen location. Repeat the process after Focusing tracks from another Workstation or Application.





appear for typing.








Layouts: Recalling




Press Shift + Layout Mode to access the Recall Grid.



Tap a Layout from the Grid to recall and populate the channelstrips with the saved fader arrangement.

Up to 96 layouts can be stored and accessed from the Master Module. Layouts can contain empty tracks, duplicated tracks or even tracks from multiple Workstations or Applications.








Layouts: Editing




Layouts can be saved or loaded from disk to access for a specific session or to send to another system.

When Saving or Loading Layouts all are saved within a Layout Set. They can not be saved individually.




To re-arrange a Layout, **Drag** any blocks to a new location. To delete a Layout simply drag it off of the grid.




Tap Done to exit the Layouts Grid.











Console Setup 1/2







Select the Frame Depth & Width of your console

Drag the modules down to the empty frame to match your configuration


Drag a blank from above to remove a module from your configuration






Console Setup 2/2






Confirm the location of the flashing module by touching any control on it. Repeat this process for all the additional modules in order



Drag the numbered display modules down to the matching frame location




Press Done to accept the configuration and complete the process






Workstations




Press WS from the Master Module to access the Workstations Page.



Drag a Workstation from the list of Network machines to the Connected list.



Double Tap the top of the Connected Workstation to Rename it.




When switching between multiple Workstations, the Attentioned Workstation is indicated in Blue.



Monitor Window






Touch Monitoring to access the Monitor Control Window.

Control Room 1/3

YA


Control Room Sources



Touch to enable any of the Control Room Sources. Touch All to enable All Sources.

XMON App





The XMON App enables communication between the S6 Surface and the XMON Monitoring Interface.

Speaker Enables



Touch to enable individual speakers for the currently selected control room source. Main is currently shown. Touch All to enable all speakers for Main.



Click and hold on XMON App to assign the MIDI Port.







Monitor Window

Control Room 2/3





Studio Communication controls. Select sources and set levels for headphones, cues and studio loudspeakers.






Touch the letter for the Monitor Source to be assigned then select the Input Sources

to feed the chosen monitor.

Output level controls for Talkback, Dim Value and the Main Control Room



Dim Level

Control Room Level







Control Room 3/3



[Return to Index]





Copyright 2014 Avid Technology, Inc.

O O



Console Preferences






Surface		
Banking		
Mode:		
8 Strips		
Whole Surface		
☐ Auto-Bank to Selected Track		
Auto-Bank to Attentioned Track		
Brightness		
☐ Auto		
Touchscreen		
10 %	100 %	100 %
OLED, LED, Display Module		
10 %	100 %	70 %
Console Timeout		
1 min	2 hrs	20 mins
✓ Softkey LEDs Enabled		

Banking & Brightness

Workstation
General
✓ Workstation Follows Knob Set Changes
✓ Open Plug-ins on Workstation When Editing
Close Plug-ins on Workstation When No Longer Editing
Solo
Mode:
O Solo In Place
After-Fader Listen
O Pre-Fader Listen
KVM Switch
KVM Switch Support:
Disabled
Gefen (serial)
Guntermann and Drunck (serial)

General, Solos & KVM



Display & Waveforms





Local Options



Home	
Attention Tracks from Meter Scroller	
☑ Display Selection/Attentioned Track Border on Meter Scroller	
☐ Track Scroller Follows Attentioned Track	
☑ Link Meter Scroller to Track Scroller	
Knob View:	
All Functions	
Selected Function	
Auto Show Function Graph on Knob Touch	

Home Options

rack Selector
Channel Selection Mode:
○ Sum
Intercancel
Solo Switch:
O Sum
O Intercancel
Position:
Always Start with Channel 1 on All Page
 Last Position of Track Selector
Attentioned Track
☑ Display Breaks on Track Color


Tracks View Options



KVM Switching








Automatic KVM Switching is supported for Gefen and G&D switchers. When enabled, **Attentioning** a workstation from the **Workstations** page will also change the attached computer display.










Guntermann & Drunck KVM





WSControl



S6 and the Workstation controlling it must be set to the same Desk ID. Each Workstation connected to S6 is required to have a unique Desk ID.

The Master Module default address is 192.168.2.1



Diagnostics

Tap any module image above to get detailed status information.

Surface

Desk ID (changes require restart)

22

WSControl, by default, is set to automatically launch on login.


To set the Desk ID use the Local Options at the bottom of the Surface page.

Desk ID has been changed, application will restart automatically in 7 second(s). Please tap Restart to restart now or Cancel to abort and return to previous Desk ID






Diagnostic Mode



To Enable Diagnostic Mode, Hold the Leftmost Top 2 Buttons on the module for 3-5 seconds. Avid Logos will confirm that you are in Diagnostics Mode.







Touchscreen Calibration


Press Settings from the Master Module then choose About

Press Logout on the touch screen

Touch the Administrator Login Icon (password = password)



Press File Explorer to browse the hard drive



From the left hand column choose Computer

Navigate to Primary (C:) by double tapping

Navigate to Program Files then Touch Panel Calibration Tool

Double Tap on WDT8650_PTool_2008 to Run it

Press Start (Do Not touch the screen during the Calibration)

After running, an error message will appear: "Access to the path 'C:\Program Files\Touch Panel Calibration Tool\ptool_testlog.txt' is denied."

Disregard and Close the application

Swipe from the right edge of the screen left to Log Out Press Start, then Administrator in the upper right corner Press Sign Out


Touch the Avid S6 User Icon to return to S6








Updating S6 Software



Download the S6 Master Module software from your MyAvid Account


Copy the unzipped .exe file named S6MasterModuleInstall to the top level of a USB transfer drive



Press Settings from the Master Module then choose About

Press Logout on the touch screen

Touch the Administrator Login Icon (password = password)





Insert the USB transfer drive into the back of the Master Module

Navigate to the USB transfer drive Removable Disk (E:)

Copy the S6MasterModuleInstall file to the Desktop

Run the S6MasterModuleInstall file by double tapping it

Follow the On-Screen Instructions.

